
Hall Effect


James Amidei



Theory

- Charged particles in motion experience a force when in the presence of a magnetic field.
- This force results in a voltage difference that is orthogonal to the current.
- We can use this voltage to find the resistivity, mobility, as well as the number and type of majority charge carriers.

$$\vec{F}_B = q\vec{v} \times \vec{B}$$
 (force due to magnetic field)
 $\vec{F}_E = q\vec{E}_u\hat{u} = q\frac{V_H}{w}\hat{u}$ (electrostatic force)




Instrumentation: Source Measure Unit

- We used a Keithley 2450
 SourceMeter
- Functions as voltage source, a current source, a voltmeter, and an ammeter.
- Used to generate a current in order to detect a voltage.
 - Current set between 0-500 microamps
 with 10 microamp step size.
 - Source limit set to 2 volts with a source delay of 0.1 seconds.



Data Analysis







Figure A: Measurement for B-C. Resistance is slope of line of best fit: V = 87.851 I. This was used, along with the area and length to find the resistivity.

- Voltage source connected from A-D and Voltmeter connected across B-Q, B-R, C-Q, and C-R.
- Resistivity found by measuring voltage from B-C and Q-R.
 - Resistivity: 0.00729 Ohm-meter +/- 0.0013 Ohm-meters

$$\rho = R \frac{A}{l} = R \frac{wt}{l} \quad \text{(resistivity)} \qquad n = \frac{B}{qtR_H} \quad \text{(carrier number)}$$

$$\mu = \frac{1}{nq\rho} \quad \text{(mobility)}$$



Drawing of experimental setup.




Figure B): From B-Q, w/ magnetic field present.




Figure C): From C-Q w/ magnetic field present.




Figure D): From B-Q w/o magnetic field present.




Figure E): B-Q w/ magnetic field minus B-Q w/o magnetic field. **V = (-0.857 +/- 0.003) I**




Figure F): C-R w/ magnetic field minus B-Q w/o magnetic field. **V** = (-0.954 +/- 0.004) I


- Charge carrier number and type found using the Hall voltage and Hall resistance.
 - R_h = 0.8525 Ohms +/- 0.0035 Ohms (B-Q) -and- 0.971 Ohms +/- 0.006 Ohms (C-R)
 - N = 1.4e21 +/- 4.46e19 (B-Q) -and- 1.22e21 +/- 4.51e19 (C-R)
 - Majority charge carriers: positively charged holes.
- Mobility found once we knew carrier number and resistivity.
 - Mobility: 0.615 (Coulomb-Ohm-meter)^-1 +/- 0.107 (Coulomb-Ohm-meter)^-1 (B-Q) -and- 0.701 (Coulomb-Ohm-meter)^-1 +/- 0.123 (Coulomb-Ohm-meter)^-1 (C-R)

Hall Effect Sensors

 Used to detect the strength and direction of external magnetic fields.

 Especially effective in environments where there is dust, water, or any other distorting elements.

 Used in automobiles as wheel speed sensors or crankshaft position sensors.



References

- Picture on title slide: https://commons.wikimedia.org/wiki/File:Hall_effect.png
- Picture on "Theory" slide:
 http://hyperphysics.phy-astr.gsu.edu/hbase/magnetic/Hall.html
- Picture on "Instrumentation" slide: Keithley 2450 Sourcemeter manual.
- Picture on "Hall effect sensor" slide:
 https://www.youtube.com/watch?v=wpAA3geOYil (Screenshot from 3:20)